

GPRS Wireless Setup

1. Open web browser on your GPRS mobile phone.
2. Type in this IP address "http://www.cpcamglobal.com/mobile/mobile.htm" and Choose "Submit"
3. Pick the right Application for your Cell phone and DVR from the download page.

Application Download Page:



[GPRS_3G_Software](#): J2ME AP for Network MJPEG format DVR

[EagleEyes\(J2ME_New Version\)](#): J2ME AP for Network MPEG4/H.264 format DVR& IP camera

[EagleEyes\(For WinCE\)](#): WinCE AP for Network MJPEG format DVR

[EagleEyes\(For WinCE New Version\)](#): WinCE AP for Network MPEG4/H.264 format DVR& IP camera

[EagleEyes for BlackBerry](#): BlackBerry APP for Network MPEG4/H.264 format DVR& IP camera

For WinCE AP:

The application only supports Windows Mobile 5.0 PocketPC and 6.0 Professional OS.

For BlackBerry:

The application only supports BlackBerry 4.6 OS and up.

For Apple I Phone:

The application available through Apple App store using your phone search the app store for EagleEyes and install it on your phone .

For 3G/GPRS AP:

- 1) Supports J2ME.
- 2) Supports Internet browsing.
- 3) The Port Number of the device you want to connect can't be 80. It's recommended to use 888

Viewing:

1. Open application in
2. Type in your video server IP / domain name and port, also the username and Password on video server (AP)
3. After click connect, wait about 3-15 second for GPRS connection.
4. AP interface will be shown and will see "16CHDVR Online" on title
5. Wait 6 second for video signal.
6. After video is shown, then you can use all the function on AP to remote managing your DVR.